# NORO



## FLEXLINE UNDER CABINET MODEL 156.1 1200 WHITE MATTE

Item number: 60832

Flexline is bathroom furniture with a timeless design and many options. The furniture is available in variants with both doors and drawers with Soft Close function, in widths of 600 and 1200 mm and with several different designs on the fronts that add character to your furniture. A luxurious freestanding sink on a worktop in Solid Surface marble or black worktop is included.

#### Included articles

3046	1 x front 2pcs 600 white matte (flexline/living/grand)
3042	$2 \times$ undercab.for door 300 white m. (flexline/living/grand)
3065	1 x topplate s.surface 1200 marble (flexline)

- 1 x topplate s.surface 1200 marble (flexline)
- 3041 1 x undercab.for drawer 600 white m. (flexline/living/grand)
- 3054 2 x door 300x500 white matte (flexline/living/grand)
- 0212 1 x basin peak 400 porcelain noro art. no. 0212

## Detailed information

ltem number		Material and surface treatment	
EAN	7340032419412	Front material	MDF
Standards and classifications		Body material	Chipboard
ETIM	EC011381	Surface treatment	Lacquered
Product dimensions and weight		Surface finish	Matt
Width	1205	Packaging dimensions and weight	
Depth (mm)	420	Package height(m)	0,415
Height (mm)	632	Package width (m)	1,122
Net weight (kg)	73	Package depth(m)	0,300
		Package weight(kg)	76,200

### Care instructions

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.