



UNDER CABINET FIX TREND WHITE MATTE WITH BASIN 550

Item number: 1314

Fix Trend 550 is a modern bathroom furniture with porcelain washbasin, perfect for a small bathroom. The shallow porcelain washbasin is only 320 mm deep and has a practical storage surface, while the overflow protection provides extra security in everyday life.

The Fix Trend cabinet, 55 cm wide, can easily be combined with Noro mirrors or mirror cabinets. The cabinet has drawers with Soft Close function and comes assembled with chrome handles included. Purchase valve push and water trap 321010. For extra storage, we recommend the Multi high cabinet in a matching colour.



The mark of
responsible forestry
FSC® C220675

Detailed information

Item number

NOBB	46183824
RSK	8972852
EAN	7340032413144
Stocked article	Yes

Standards and classifications

EN standard	EN14688
CE marked	Yes
ETIM	EC011382

Product dimensions and weight

Width	560
Depth (mm)	320
Height (mm)	500
Hole spacing, handle (mm)	256
Net weight (kg)	25,4

Material and surface treatment

Main material	MDF, Porcelain
Front material	MDF
Body material	MDF
Surface treatment	Lacquered
Surface finish	Matt
Color	White

Packaging dimensions and weight

Package height(m)	0,500
Package width (m)	0,590
Package depth(m)	0,365
Package weight(kg)	27,900

Miscellaneous

Opening function	Soft close
	Centered

Care instructions

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.