



## UNDER CABINET FIX TREND BLACK WOOD STRUCTURE WITH

Item number: 320413

Fix Trend 420 is a modern bathroom furniture with porcelain washbasin, perfect for a small bathroom. The shallow porcelain washbasin is only 320 mm deep and has a practical storage surface, while the overflow protection provides extra security in everyday life.

The Fix Trend cabinet, 42 cm wide, can easily be combined with Noro mirrors or mirror cabinets. The cabinet has drawers with Soft Close function and comes assembled with black handles included. Purchase valve push and water trap 321010. For extra storage, we recommend the Multi high cabinet in a matching colour.



The mark of  
responsible forestry  
FSC® C220675

### Detailed information

#### Item number

NOBB 60835621  
EAN 7340032406078

#### Standards and classifications

EN standard EN14688  
CE marked Yes  
ETIM EC011382

#### Product dimensions and weight

Width 420  
Depth (mm) 320  
Height (mm) 500  
Hole spacing, handle (mm) 160  
Net weight (kg) 22,3

#### Material and surface treatment

Main material MDF, Porcelain  
Front material MDF  
Body material MDF  
Surface treatment Melamine faced  
Color svarttrastruktur  
White

#### Packaging dimensions and weight

Package height(m) 0,500  
Package width (m) 0,460  
Package depth(m) 0,360  
Package weight(kg) 24,500

#### Miscellaneous

Opening function Soft close  
Centered

### Care instructions

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.