# noro



## FLEXLINE UNDER CABINET MODEL 165.4 1200 GREY MATTE

Item number: 60871

Flexline is bathroom furniture with a timeless design and many options. The furniture is available in variants with both doors and drawers with Soft Close function, in widths of 600 and 1200 mm and with several different designs on the fronts that add character to your furniture. A luxurious freestanding sink on a worktop in Solid Surface marble or black worktop is included.

#### Included articles

0213	1 x basin coast 405 porcelain noro art. no. 0213
3057	1 x door 300x500 grey grame (flexline/living/grand)
3042	1 x undercab.for door 300 white m. (flexline/living/grand)
3049	1 x front 2pcs 600 grey frame (flexline/living/grand)
3065	1 x topplate s.surface 1200 marble (flexline)
3041	1 x undercab.for drawer 600 white m. (flexline/living/grand)
3043	1 x sidemodule 300 white matte (flexline/living/grand)

## **Detailed information**

ltem number		Material and surface treatment	
EAN	7340032419801	Front material	MDF
Standards and classifications		Body material	Chipboard
ETIM	EC011381	Surface treatment	Lacquered
Product dimensions and weight		Surface finish	Matt
Width	1205	Packaging dimensions and weight	
Depth (mm)	420	Package height(m)	0,415
Height (mm)	680	Package width (m)	1,122
Net weight (kg)	72	Package depth(m)	0,300
		Package weight(kg)	75,300

### Care instructions

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.